

# Atmospheric and Depositional Nitrogen Monitoring

J N Cape, Y S Tang, R I Smith, M A Sutton,  
E Nemitz, D Famulari, D Fowler

Centre for Ecology & Hydrology, Edinburgh, UK

# Sources of 'reactive' N in the atmosphere

- **What to monitor**

Nitrogen oxides

**NO, NO<sub>2</sub>**

Nitric and nitrous acid

**HNO<sub>3</sub>, HONO**

Ammonia

**NH<sub>3</sub>**

Nitrate and ammonium  
in aerosols  
and precipitation

**NO<sub>3</sub><sup>-</sup>, NH<sub>4</sub><sup>+</sup>**

Organic nitrogen

**various...  
PAN, urea, amines etc.**

# Sources of 'reactive' N in the atmosphere

- **What to monitor**

Nitrogen oxides

Nitric and nitrous acid

Ammonia

Nitrate and ammonium  
in aerosols  
and precipitation

Organic nitrogen

- **Where it comes from**

Combustion, soil


Oxidation of nitrogen oxides

Animal wastes, senescent  
vegetation, 3-way catalysts

Oxidation of nitrogen oxides  
Reaction with ammonia gas  
Solution of nitrate and  
ammonium aerosols

Photochemical,  
possibly agricultural

# EMITTED POLLUTANTS



SO<sub>2</sub>

NO<sub>2</sub>

NH<sub>3</sub>

particles/  
aerosols

SO<sub>4</sub><sup>2-</sup>  
NO<sub>3</sub><sup>-</sup>  
NH<sub>4</sub><sup>+</sup>

WET  
DEPOSITION

DRY  
DEPOSITION

power  
stations  
(combustion)

motor  
vehicles  
(combustion)

livestock

# How to monitor

## Continuous

- Captures short-term variations
- Helps in identification of sources
- Links to dynamic transport models
- Expensive equipment
- Expensive data analysis
- Needs electrical power

## Integrating

- Good spatial information
- Several components simultaneously
- Matches target load timescales
- Inexpensive equipment
- Needs chemical analysis
- May not need electricity

# Why to monitor

## Point source


Direct effects on local vegetation and soils

e.g. ammonia from intensive agriculture

## Regional estimate


Comparison with critical loads or target loads

e.g. deposition to sensitive ecosystem



# Spatial heterogeneity

- Important close to point sources
- Edges are 'hot spots' for deposition



Dragosits et al.  
(Environ. Pollution 2002)

# Spatial heterogeneity

- **Important features of the landscape**

Orographic enhancement of rainfall

Deposition in cloud






# Spatial heterogeneity

- **Important features of the landscape**

Orographic enhancement of rainfall

Deposition in cloud



# Deposition monitoring

## Wet deposition

- Precipitation amount



Standard rain gauge collects more rain than 'bulk' collector

Problems with quantifying snowfall


Standard precipitation amount data are more widely available than chemical data.



# Deposition monitoring

## Wet deposition

- Cloud – is it an issue?



# Deposition monitoring

## Wet deposition

- 'Bulk' or 'wet-only' ?



**Bulk:**  
Inexpensive  
No power  
Many replicates

**Wet-only:**  
Less contamination  
Preserved samples



# Deposition monitoring

## Wet deposition

- 'Bulk' or 'wet-only' ?



**Bulk:**  
Contamination  
Sample storage



**Wet-only:**  
Not artefact-free  
Problems with amounts  
Needs electricity  
Expensive



# Deposition monitoring


## Wet deposition

- Quality control - check for contamination (K, P)
- Missing values - use predictions to fill gaps



# Interpolation and extrapolation


generating a concentration map




more sites gives more definition ( $\text{HNO}_3 \rightarrow \text{SO}_4^{2-}$ )  
extra information improves structure ( $\text{SO}_4^{2-} \rightarrow \text{NO}_2 \rightarrow \text{NH}_3$ )

# Interpolation and extrapolation


generating a deposition map



X



=>



Interpolated concentration


Precipitation amount

Interpolated deposition




# Interpolation and extrapolation

- **Uncertainty estimates**



30 site network for non-seasalt SO<sub>4</sub><sup>2-</sup> in 1996

Map of kriged standard error and results of cross-validation study (predicted mean for omitted sites with 95% confidence intervals)



# Deposition monitoring

## Wet (+ dry) deposition

- Throughfall measurements
  - good for estimating deposition of conserved species (e.g. sulphate) provided sampling design is adequate
  - only works for forests
  - unreliable for non-conserved species, e.g. ammonium and nitrate



# Deposition monitoring

## Dry deposition


- Direct measurement

Need to measure the **flux** of a gas or particles from the atmosphere to the surface, or *vice versa*.

Transport occurs through atmospheric turbulence and diffusion.

$$\text{flux}\chi = \overline{w'\chi'}$$

$w'$  - fluctuation in vertical wind speed  
 $\chi'$  - deviation from mean concentration



# Deposition monitoring


## Dry deposition

- Direct measurement

In practice this means measuring separately the concentration in the upward-moving eddies and the downward-moving eddies.

$$\text{flux}\chi = \overline{w'\chi'}$$

$w'$  - fluctuation in vertical wind speed  
 $\chi'$  - deviation from mean concentration




# Deposition monitoring

## Dry deposition

- Direct measurement

To capture the eddies we need fast (10 Hz) measurements of wind speed and direction, and simultaneous fast measurements of the concentration



# Deposition monitoring

## Dry deposition


- Direct measurement

The analytical detectors are expensive, e.g. tunable diode lasers.

Real-time fluxes allow us to understand the processes controlling deposition.




Easter Bush, August 10<sup>th</sup>-11<sup>th</sup>, 2002  
TDL NH<sub>3</sub> concentrations and fluxes



# Deposition monitoring

## First Intercomparison of TDL-AS for $\text{NH}_3$ fluxes




Eddy covariance for  $\text{NH}_3$  now possible  
– but still not easy

# Deposition monitoring

## Dry deposition

- Understanding the processes



Depend on wind speed and turbulence

$$V_d = \frac{\text{flux}}{\text{concentration}} = \frac{1}{R_t}$$

$$R_t = R_a + R_b + \left( \frac{1}{R_{c1}} + \frac{1}{R_{c2}} + \frac{1}{R_{c3}} \right)^{-1}$$

Depend on properties of the surface




# Deposition monitoring

## Dry deposition

- Indirect measurement – eddy accumulation

A fast-switching valve is used to direct air from upward- and downward-moving eddies into separate “containers” which can be analysed slowly.


Time resolution is ~ 30 min.



# Deposition monitoring

## Dry deposition

- Indirect measurement – eddy accumulation




Continuous relaxed eddy accumulation  
(REA) system for NH<sub>3</sub>

# Deposition monitoring

## Dry deposition


- Indirect measurement – flux gradient



# Deposition monitoring

## Dry deposition

- Indirect measurement – flux gradient



$$\text{flux}\chi = K\chi \frac{\partial\chi}{\partial z}$$


with stability correction:

$$\text{flux}\chi = ku_* \frac{\partial\chi}{\partial[\ln(z-d) - \Psi_H\{\zeta\}]}$$

# Deposition monitoring


## Dry deposition

- Indirect measurement – flux gradient
- Typical 30 min data.
- Requires adequate fetch and wind speed.
- Theory does not work under some conditions.
- Can use 'slow' analyzer
- Data processing takes a long time



# Deposition monitoring

## Measured and modelled $\text{SO}_2$ flux at Auchencorth Moss over 5 days



# Deposition monitoring


## Dry deposition – comparison of measurements

	<b>Eddy covariance</b>	<b>Flux gradient</b>
Equipment cost (\$)	2-500,000	~ 20,000
Equipment maintenance	Labour intensive	Automated
Skills required	Post-doc	Graduate
Time resolution	second	hour
Data processing	Labour intensive	Moderate

# Deposition monitoring

## Dry deposition

- **Conditional time-averaged gradient (COTAG)**
- 1-4 week averaged flux of  $\text{NH}_3$ ,  $\text{SO}_2$  (and other trace species, e.g. particles)
- Concentration and turbulence, temperature, wind direction, stability, heat flux also provided






# Deposition monitoring

## Dry deposition

- **Conditional time-averaged gradient (COTAG)**

wind and solar powered



wind direction

samplers


wind speed

# Deposition monitoring

## Dry deposition

- Conditional time-averaged gradient (COTAG)

Two-weekly measurements of ammonia fluxes at Auchencorth Moss: Sep 02 – Aug 03




# Deposition monitoring

## Dry deposition

- Inferential methods

Combine measured or modelled concentrations with measured or modelled deposition velocities ( $v_d$ ):

$$\text{flux} = v_d \times \text{concentration}$$






# Deposition monitoring

## Dry deposition - Inferential methods

HNO<sub>3</sub> concentration

Deposition model

HNO<sub>3</sub> deposition




Depends on land use / vegetation

# Deposition monitoring

## Dry deposition - Inferential methods

Measured concentration + modelled depn velocity

**spatially interpolated**      **vegetation dependent**



**Vegetation dependence** involves seasonal changes in:

- vegetation height (roughness)
- leaves present/absent
- foliage active/dormant

**Wind speed dependence** of deposition velocity can be based on measurements

# Concentration monitoring

- Continuous gas analyzers

Useful for near-source 'acute' exposure estimates and source attribution, but expensive for area estimates

- Integrating methods


Active methods require power (but may be wind/solar)

Passive methods do not

Both can provide data adequate for deposition estimation

# Concentration monitoring

- Low-cost active monitoring of trace gases and aerosols (**DELTA**)



Long denuders 1+2  
To remove  $\text{HNO}_3$ ,  $\text{SO}_2$  and  
 $\text{HCl}$

Shorter denuders 3 + 4  
To remove  $\text{NH}_3$

Aerosol filter  
To remove particulate  
 $\text{NH}_4^+$ ,  $\text{NO}_3^-$ ,  $\text{SO}_4^{2-}$ ,  $\text{Cl}^-$ , and  
base cations  $\text{Na}^+$ ,  $\text{Ca}^{2+}$ ,  
 $\text{Mg}^{2+}$


Air inlet

pump


# Concentration monitoring

## Example time series of monthly monitoring

Strathvaich Dam  
Remote Scottish Upland Site




Sutton Bonington  
SO<sub>2</sub> Source Region



1999 - 2005




# Implementation in NitroEurope



- **'Level 1' (50 sites)**  
continuous concentration measurements (**DELTA**) and measured atmospheric turbulence
- + **'Level 2' (9 sites)**  
continuous flux measurements using COTAG systems
- + **'Level 3' (13 sites)**  
continuous flux measurements using eddy covariance and/or gradient techniques

# Concentration monitoring

## Passive sampling – examples for ammonia




Passive diffusion tube  
with membrane to reduce  
effects of wind turbulence

Slow sampling rate

3.5 cm  
Membrane  
DT

CEH ALPHA sampler  
Fast sampling rate




6 mm

### KEY

- Impregnated filter / grid
- ..... Membrane

1996-2001  
interpolated



# Use of models to estimate deposition

## How do we assess uncertainty?

- Comparison with measurements –  
but beware of comparing point measurements with area estimates, even at 1 km x 1 km.
- Sensitivity analysis –  
which model parameters are critical?
- Typical uncertainties are factor 2 for individual 20 x 20 km grid annual deposition estimates.

# Priorities for Alberta

## Wet deposition

- Ammonium-N: 0.2 – 2 kg N ha<sup>-1</sup> y<sup>-1</sup>
- Nitrate-N: 0.1 – 1 kg N ha<sup>-1</sup> y<sup>-1</sup>
- Inorganic-N: 0.3 – 3 kg N ha<sup>-1</sup> y<sup>-1</sup>
- Organic-N: ?

**Concentrations**

0.1 – 1 mg N litre<sup>-1</sup>

**Precipitation**

150 – 600 mm y<sup>-1</sup>

# Priorities for Alberta

## Dry deposition Concentrations

- Ammonia : 1 – 20  $\mu\text{g m}^{-3}$  (median 5)
- Nitric acid : ? 0.3  $\mu\text{g m}^{-3}$
- Nitrogen dioxide : 2 – 60  $\mu\text{g m}^{-3}$  (median 12)
- Particulate nitrate: ? 1  $\mu\text{g m}^{-3}$

[[www.casadata.org](http://www.casadata.org); Peake et al., 1988]

## Deposition velocities

- Ammonia : 0 – 10  $\text{cm s}^{-1}$  ( $\text{SO}_2$ , wetness)
- Nitric acid : 0.5 – 10  $\text{cm s}^{-1}$  (no surface resist.)
- Nitrogen dioxide : 0.1 – 0.3  $\text{cm s}^{-1}$  (stomatal)
- Particulate nitrate: 0.01 – 1  $\text{cm s}^{-1}$  (size dependent)

# Priorities for Alberta

## Dry deposition

### Concentrations x deposition velocities

- Ammonia : 0 – 50 (rural 1-5) kg N ha<sup>-1</sup> y<sup>-1</sup>
- Nitric acid : ? 1 kg N ha<sup>-1</sup> y<sup>-1</sup>
- Nitrogen dioxide : 0.3 – 9 (median 2) kg N ha<sup>-1</sup> y<sup>-1</sup>
- Particulate nitrate: ? <1 kg N ha<sup>-1</sup> y<sup>-1</sup>

**Total dry N deposition: several kg N ha<sup>-1</sup> y<sup>-1</sup>**

**cf. wet deposition 0.3 – 3 kg N ha<sup>-1</sup> y<sup>-1</sup>**

# Comparison with models

- Comparing like with like – point vs. area
- Need to estimate area deposition from monitoring data
- Use models for receptor-specific estimates
- Local vs. regional scale


# Deposition Monitoring Summary

- Identify purpose – why? what? where?
- Identify temporal resolution required
- Decide on precision acceptable
- Identify resources available – how to do it?
- Decide relationship with modelling
- Consider uncertainty analysis






# Case Study: Ammonia emissions



IF: Intensive Farm  
MF: Mixed Farm


Dragosits et al.  
(Environ. Pollution  
2002)

# Modelled ammonia concentrations



Exceedance of the annual critical level for NH<sub>3</sub> is predicted up to 500 m from the intensive farm, but only in the immediate vicinity of the mixed farms

# Modelled ammonia dry deposition



The largest NH<sub>3</sub> Deposition occurs Near the intensive Farm and at the edges Of woodland and Semi-natural land.

Deposition is less In the centre of large Semi-natural areas.

# Exceedance of critical loads for nitrogen at a field scale

